

19 Series Exit Device Template Index Wood Door Applications

19 Series Device	Device Template
19-R, F-19-R	W-1100
19-V, F-19-V, 19-V-LBR, F-19-V-LBR	W-1105

19 Series Device	19 Series Trim	Trim Template
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	917DT, 930C, 930DT, 930NL, 930EO	W-2123
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	920DT, 920NL	W-2124
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	930DT narrow stile, 930NL narrow stile	W-2126
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	911K, 912L	W-2190
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	918DT, 918NL	W-2191
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	913KIK, 914KIL	W-2131

19 Series Device	19 Series Strike	Strike Template
F-19-R	F-570 (standard) 490, F-490 (optional)	W-3001
19-R, F-19-R	565	W-3006
19-R, F-19-R	571, 571-A	W-3003
19-V, F-19-V, 19-V-LBR, F-19-V-LBR	3788 Top Strike with 4215 angle bracket (standard)	W-3032*
19-V, F-19-V	2130 Bottom Strike (standard)	W-3053
	2126-A Bottom Strike (optional)	W-3050
	4155 Bottom Strike (optional)	W-3055

* For F-19-V-LBR applications, add template [W-5494](#) for Auxiliary Fire Latch.